
## Overview of Mass Storage Structure

- Magnetic disks provide bulk of secondary storage
  - Drives rotate at 70 to 250 times per second
    - Ipod disks: 4200 rpm
    - Laptop disks: 4200, 5400 rpm or 7200 rpm
    - Desktop disks: 7200 rpm
    - Server disks: 10000 rpm or 15000 rpm
  - **Transfer rate** is rate at which data flow between drive and computer
  - Positioning time (random-access time) is time to move disk arm to desired cylinder (seek time) and time for desired sector to rotate under the disk head (rotational latency)
  - Head crash results from disk head contacting disk surface
    - That's bad
- Disks can be removable
- Drive attached to computer via I/O bus
  - Busses vary, including EIDE, ATA, SATA, Firewire, USB, Fibre Channel, SCSI
  - Host controller in computer uses bus to talk to disk controller built into drive or storage array




# Moving-head Disk Mechanism






## Disk drives







# Hard disk head, platter and disk crash



3/26/06

Principles

page 4

#### Disk Structure

- Disk drives are addressed as large 1-dimensional arrays of *logical blocks*, where the logical block is the smallest unit of transfer.
- ▶ The 1-dimensional array of logical blocks is mapped into the sectors of the disk sequentially.
  - Sector 0 is the first sector of the first track on the outermost cylinder.
  - Mapping proceeds in order through that track, then the rest of the tracks in that cylinder, and then through the rest of the cylinders from outermost to innermost.



#### Magnetic tape

- Was early secondary-storage medium
- Relatively permanent and holds large quantities of data
- Access time slow
- ▶ Random access ~1000 times slower than disk
- Mainly used for backup, storage of infrequentlyused data, transfer medium between systems
- Kept in spool and wound or rewound past readwrite head
- Once data under head, transfer rates comparable to disk
- ▶ 20-200GB typical storage
- Common technologies are 4mm, 8mm, 19mm, LTO-2 and SDLT



# Tape pictures



## Tape Drives

- ▶ The basic operations for a tape drive differ from those of a disk drive.
- locate positions the tape to a specific logical block, not an entire track (corresponds to seek).
- ▶ The **read position** operation returns the logical block number where the tape head is.
- The space operation enables relative motion.
- Tape drives are "append-only" devices; updating a block in the middle of the tape also effectively erases everything beyond that block.
- An EOT mark is placed after a block that is written.



## **Application Interface**

- ▶ Most OSs handle removable disks almost exactly like fixed disks a new cartridge is formatted and an empty file system is generated on the disk.
- ▶ Tapes are presented as a raw storage medium, i.e., and application does not not open a file on the tape, it opens the whole tape drive as a raw device.
- Usually the tape drive is reserved for the exclusive use of that application.
- Since the OS does not provide file system services, the application must decide how to use the array of blocks.
- Since every application makes up its own rules for how to organize a tape, a tape full of data can generally only be used by the program that created it.



## Tertiary Storage Devices

- Low cost is the defining characteristic of tertiary storage.
- Generally, tertiary storage is built using removable media
- Common examples of removable media are floppy disks and CD-ROMs; other types are available.



#### Removable Disks

- ▶ Floppy disk thin flexible disk coated with magnetic material, enclosed in a protective plastic case.
  - Most floppies hold about 1 MB; similar technology is used for removable disks that hold more than 1 GB.
  - Removable magnetic disks can be nearly as fast as hard disks, but they are at a greater risk of damage from exposure.



## Removable Disks (Cont.)

- A magneto-optic disk records data on a rigid platter coated with magnetic material.
  - Laser heat is used to amplify a large, weak magnetic field to record a bit.
  - Laser light is also used to read data (Kerr effect).
  - The magneto-optic head flies much farther from the disk surface than a magnetic disk head, and the magnetic material is covered with a protective layer of plastic or glass; resistant to head crashes.
- Optical disks do not use magnetism; they employ special materials that are altered by laser light.



#### **WORM Disks**

- The data on read-write disks can be modified over and over.
- WORM ("Write Once, Read Many Times") disks can be written only once.
- ▶ Thin aluminum film sandwiched between two glass or plastic platters.
- ▶ To write a bit, the drive uses a laser light to burn a small hole through the aluminum; information can be destroyed by not altered.
- Very durable and reliable.
- Read Only disks, such ad CD-ROM and DVD, come from the factory with the data pre-recorded.



## **Operating System Issues**

- Major OS jobs are to manage physical devices and to present a virtual machine abstraction to applications
- For hard disks, the OS provides two abstraction:
  - Raw device an array of data blocks.
  - File system the OS queues and schedules the interleaved requests from several applications.



## File Naming

- ▶ The issue of naming files on removable media is especially difficult when we want to write data on a removable cartridge on one computer, and then use the cartridge in another computer.
- Contemporary OSs generally leave the name space problem unsolved for removable media, and depend on applications and users to figure out how to access and interpret the data.
- Some kinds of removable media (e.g., CDs) are so well standardized that all computers use them the same way.



## Speed

- ▶ Two aspects of speed in tertiary storage are bandwidth and latency.
- Bandwidth is measured in bytes per second.
  - Sustained bandwidth average data rate during a large transfer; # of bytes/transfer time.
    Data rate when the data stream is actually flowing.
  - Effective bandwidth average over the entire I/O time, including **seek** or **locate**, and cartridge switching. Drive's overall data rate.



## Speed (Cont.)

- Access latency amount of time needed to locate data.
  - Access time for a disk move the arm to the selected cylinder and wait for the rotational latency; < 35 milliseconds.</p>
  - Access on tape requires winding the tape reels until the selected block reaches the tape head; tens or hundreds of seconds.
  - Generally say that random access within a tape cartridge is about a thousand times slower than random access on disk.
- The low cost of tertiary storage is a result of having many cheap cartridges share a few expensive drives.
- A removable library is best devoted to the storage of infrequently used data, because the library can only satisfy a relatively small number of I/O requests per hour.



## Reliability

- A fixed disk drive is likely to be more reliable than a removable disk or tape drive.
- An optical cartridge is likely to be more reliable than a magnetic disk or tape.
- A head crash in a fixed hard disk generally destroys the data, whereas the failure of a tape drive or optical disk drive often leaves the data cartridge unharmed.




#### Cost

- Main memory is much more expensive than disk storage
- The cost per megabyte of hard disk storage is competitive with magnetic tape if only one tape is used per drive.
- The cheapest tape drives and the cheapest disk drives have had about the same storage capacity over the years.
- Tertiary storage gives a cost savings only when the number of cartridges is considerably larger than the number of drives.




#### Price per Megabyte of DRAM, From 1981 to 2004






#### Price per Megabyte of Magnetic Hard Disk, From 1981 to 2004






#### Price per Megabyte of a Tape Drive, From 1984-2000





#### **Network-Attached Storage**


- Network-attached storage (NAS) is storage made available over a network rather than over a local connection (such as a bus)
- NFS and CIFS are common protocols
- Implemented via remote procedure calls (RPCs) between host and storage
- New iSCSI protocol uses IP network to carry the SCSI protocol





## Storage Area Network

- Common in large storage environments (and becoming more common)
- Multiple hosts attached to multiple storage arrays flexible



# Hierarchical Storage Management (HSM)

- A hierarchical storage system extends the storage hierarchy beyond primary memory and secondary storage to incorporate tertiary storage — usually implemented as a jukebox of tapes or removable disks.
- Usually incorporate tertiary storage by extending the file system.
  - Small and frequently used files remain on disk.
  - Large, old, inactive files are archived to the jukebox.
- ▶ HSM is usually found in supercomputing centers and other large installations that have enormous volumes of data.

